Hose Type 6/4HT

High Temperature to 300°F (+150°C)



Applications

Oil and Gas: Chemical Injection, Gaseous Media Handling,

Methanol Injection, Nitrogen Service

Inner Core:

4 layers of high-tensile steel wire Pressure Support:

Outer Cover: **PVDF**

Colour: grey, other colours upon request -4°F to 300°F [-20°C to +150°C] Temperature:



Ø ID	Ø OD	Working Pressure*)	Burst Pressure ¹)	Min. Bend Radius	Weight	Nipple Ø ID	Sleeve	Sleeve Ø OD
0,25 inch	0,50 inch	15.730 psi	55.100 psi	11,02 inch	0,215 lbs/ft	0,14 inch	10640101 carbon steel	0,65 inch
6,3mm	12,6 mm	1.085 bar	3.800 bar	280 mm	0,320 kg/m	3,5 mm	10640105 AISI 316Ti	16,4 mm

Fittings: ID6, Series B and Y

Description	Size	Material	Part Number		
HP fitting	3/8"x24 UNF LH	AISI 316Ti 40640205B		1 00	
HP fitting BLAST PRO ²)	3/8"x24 UNF LH	stainless steel carbon steel	40640214Y sleeve / 10640232	3	
HP female BLAST PRO ²)	3/8"x24 UNF	stainless steel carbon steel	40640234Y sleeve / 10640232	Fenale BLAST PRD waterblast fitting	
male fitting	1/4"x18 NPTF	carbon steel	30640401B	three	
male fitting with 60° cone	G1/4"	carbon steel	30640301B		
BSP female swivel	G1/4"	carbon steel carbon steel AISI 316 Ti	20640301B swivel nut / 50540301 swivel nut / 50540305	2 Pe	
metric female swivel with O-Ring	M18x1.5	carbon steel	20640241B / 50620201	X O-Ring	
Type M female swivel	9/16"x18 UNF	carbon steel	20640641B / 50540601		
Type M female swivel	9/16"x18 UNF	AISI 316Ti	20640645B / 50540605		
JIC female swivel	9/16"x18 UNF	AISI 316Ti	20640655B / 50540605	* P	

---- Additional fittings are available upon request. ----

Important Information!

In case of accidental leakage when transferring hot medium through SPIR STAR hoses the potential for injury exists from escaping fluids at high temperature (up to 150°C or 300°F) while under pressure. When used for this purpose SPIR STAR HT series hoses should only be used when there is appropriate protecting devices in place to rule out the possibility of injury. The protecting devices may be removed only (e.g. for repairs) after the hose assembly has been depressurized and cooled to ambient temperature.

^{*)} BLAST PRO fittings must only be used for tube cleaning operation inside the tube. They are not designed for the use outside of tubes.

*) The safety factors between the burst pressure and the working pressure as well as the test pressure depend on the operating conditions. For gaseous media the outer cover is to be pinpricked. Regarding the safety factor for gaseous media please contact your local SPIR STAR® assembling center. The indicated working pressure refers to the hose only. Depending on the used fitting the permitted working pressure of a hose assembly can be less. We reserve our rights for changes without notice.



© Copyright by SPIR STAR® | revised on 18.09.2009

¹⁾Production related variations up to 5 % are possible